




BMPM007

Parts Breakdown

7 Quart Planetary mixer

BMPM007 PARTS BREAKDOWN

IMAGE: BM007-01



ILLUS. BM007-1	PARTS NAME	QTY
1	Top Cover	1
2	Retainer	
3	Mixer Head and Column	1
4	Center Shaft	
5	Gear-Center Shaft	1
6	Spacer	1
7	Worm Gear Shaft	
8	Worm Gear	
9	Gear-Worm Gear Shaft	
10	Motor (100-120V) or (200-240V)	1
11	Control Board	1
12	IC Board (100-120V) or (200-240V)	1
13	Planetary Gear	1
14	Internal Gear	
15	tiead Ring [<i>for</i> BMPM007 model only)	1
16	Planetary Head	1
17	Planetary Shaft	1
18	Tapered Pin	1
19	Rear Plate of Column	1
20	Apron	1
21	Base	1
22	Bowl Support	
23	Bowl Pin	
24	Lifting Bar	
25	Fixed Angle Plate	1
26	Lifting Bracket	1
27	Lifting Handle	1
28	Compression Spring	
29	7 Liter Bowl	1
30	Flat Beater	1
31	Spiral Hook	1
32	Wire Whip	1
33	Cover Plug	2
34	Cover Fixed Tube	1
35	Ball Bearing	1
36	Ball Bearing	1
37	Ball Bearing	2
38	Ball Bearing	1
39	Ball Bearing	1
40	O-Ring	1
41	Oil Seal	1
42	Oil Seal	1
43	Oil Seal	1

44	Spring Pin	2
45	Spring Pin	2
46	C-Ring	1
47	C-Ring	
48	C-Ring	1
49	C-Ring	1
50	C-Ring	
51	Key	3
52	Key	1
53	Key	1
54	Plastic Plug 3/4"	2
55	Plastic Plug 53mm	1
56	Cable Connector	1
57	Cable	1
58	Plastic Tube	1
59	Bolt	4
60	Bolt	5
61	Screw	3
62	Screw	3
63	Screw	2
64	Screw	1
65	Mach. Screw	1
66	Mach. Screw	4
67	Mach. Screw	6
68	Mach. Screw	2
69	Mach. Screw	1
70	Screw	2
71	Nut	1
72	Nut	4
73	Nut	1
74	Flat Washer	1
75	Flat Washer	2
76	Flat Washer	2
77	Spring Washer	2
78	Spring Washer	6
79	Sticker of Control Panel	1
80	Back Cover (for CE model only)	
81	Front Cover (for CE model only)	1
82	Seat of Micro Switch (for CE model only)	
83	Fixed Ring	
84	Mach. Screw	4
85	Screw	2
86	Mach. Screw	4
87	Micro Switch	2
91	Carbon of Motor	2
92	Carbon Cover	2
93	Limit Switch Seat	1